

# HOW TO RESET THE BREAKERS

If an outlet or light is not working  
Please go to breaker panel and turn  
each one completely off then back  
on again.



This panel has several double  
breakers  
Normally for the kitchen counter  
plugs, stove and the dryer.

If any of these are not working  
Switch both double breakers at the  
same time completely off then back  
on again



## PLEASE REMEMBER TO TRY THIS FIRST

If an electrician or a technician is called out and they reset  
the breakers, there may be a charge to you.

